

PHILIPS

sense and simplicity

A closer look at photobiological safety measurements

Egbert Lenderink

Philips Lighting

May 4-6, 2011

Outline



- Photobiological safety standards and risk groups
- A closer look at the required measurement conditions
- Quantitative implications of measurement condition choice
- Transferring risk group information from light source to fixture
- Summary and conclusions

Photobiological safety: IEC 62471

4.	EXPOSURE LIMITS (EL'S).....	25
4.1	General	25
4.2	Specific factors involved in the determination and application of retinal exposure limits ..	27
4.2.1	Pupil diameter.....	27
4.2.2	Angular subtense of source and measurement field-of-view	27
4.3	Hazard exposure limits.....	29
4.3.1	Actinic UV hazard exposure limit for the skin and eye	29
4.3.2	Near-UV hazard exposure limit for the eye	31
4.3.3	Retinal blue light hazard exposure limit.....	33
4.3.4	Retinal blue light hazard exposure limit - small source	37
4.3.5	Retinal thermal hazard exposure limit.....	39
4.3.6	Retinal thermal hazard exposure limit – weak visual stimulus.....	39
4.3.7	Infrared radiation hazard exposure limits for the eye	41
4.3.8	Thermal hazard exposure limit for the skin	41
5.	MEASUREMENT OF LAMPS AND LAMP SYSTEMS	43
5.1	Measurement conditions.....	43

Blue light hazard

- Leading cause of eye damage after looking into sun, welding arcs, etc.
- Photochemical damage of retina
- Action spectrum described, peaks around 450 nm
- Radiation density on retina depends partly on *luminance* of the source



Exposure limits: large source

- Source is imaged over a certain area of the retina
- **Luminance of the source** determines the local illuminance at the retina, and is therefore used to set the exposure limit
- Quantity L_B : blue-light weighted radiance, unit W/m^2sr
- Large source if subtended angle $>$ specified viewing angle

For a weighted source radiance, L_B , exceeding $100 W \cdot m^{-2} \cdot sr^{-1}$, the maximum permissible exposure duration, t_{max} , shall be computed:

$$t_{max} = \frac{10^6}{L_B} \quad s \quad (\text{for } t \leq 10^4 \text{ s}) \quad (4.6)$$

where:

t_{max} is the maximum permissible exposure duration in seconds,
 L_B is the blue-light hazard weighted radiance.

Note 1: The spectral radiance L_λ shall be averaged over a right circular cone field-of-view of α_{eff} , as described in clause 4.2.2.

Exposure limits: small source

- Source is essentially not imaged sharply and/or constantly moving over retina due to eye and head movements
- **Illuminance on the eye pupil** determines the exposure limit
- Quantity E_B : blue-light weighted irradiance, unit W/m^2
- Small source if subtended angle $<$ specified viewing angle

For a source where the blue light weighted irradiance, E_B , exceeds $0,01 W \cdot m^{-2}$, the maximum permissible exposure duration shall be computed:

$$t_{\max} = \frac{100}{E_B} \quad \text{s} \quad (\text{for } t \leq 100 \text{ s}) \quad (4.8)$$

where:



t_{\max} is the maximum permissible exposure duration in seconds,
 E_B is the blue light hazard weighted irradiance.

Risk classifications and labeling requirements

risk group	t_{\max} for blue light hazard	max L_B (large source) or E_B (small source)	labeling requirement
0: Exempt	>10,000 s	100 W/m ² sr or 1 W/m ²	none
1: Low risk	100-10,000 s	10,000 W/m ² sr or 1 W/m ²	none
2: Moderate risk	0.25-100 s	4,000,000 W/m ² sr or 400 W/m ²	<p>CAUTION Possibly hazardous optical radiation emitted from this product. Do not stare at operating lamp. May be harmful to the eyes.</p>
3: High risk	<0.25 s		<p>WARNING Possibly hazardous optical radiation emitted from this product. Do not look at operating lamp. Eye injury may result.</p>

Conditions affecting outcome of measurement

- Distance
- Viewing angle
- IEC 62471 prescription:
 - general lighting services: distance where illuminance = 500 lux
 - all other or unknown applications: 200 mm
 - 0.011 rad if $t_{max} > 10$ s
 - 0.0017 rad if $t_{max} < 0.25$ s




short distance:
large source regime
 t_{max} determined by L_B

longer distance:
small source regime
 t_{max} determined by E_B

A closer look at 500 lux

- Two possibilities at the distance corresponding to 500 lux:
 - Light source is *small*: determine E_B
 - Total emission spectrum, scaled to 500 lux, weighted with the blue hazard action spectrum
 - Light source is *large*: determine L_B
 - Spectral radiance measurement from the brightest part of the source, averaged over the area corresponding to the specified viewing angle, weighted with the blue hazard action spectrum
- Measurements and calculations to gain understanding
 - focusing on sources of **white light**
 - lamps of various technologies

E_B at 500 lux measurement if in small source regime



Correlates mainly with CCT, only very slightly with spectral details related to lamp technology
 Throughout this CCT range: always below the 1 W/m² limit where $t_{max} = 100$ s


500 lux in the large source regime

- Combination of the two conditions


- $E = 500 \text{ lux}$

- *subtended angle* $> 0.011 \text{ rad}$ (large source condition)

poses an **upper limit** to the source luminance of approx **5 Mcd/m²**



Luminance value where $t_{\max} = 100$ s




Conclusion on 500 lux measurement

- No **white** light source can be measured to be higher than RG 1 at 500 lux!
 - If it is a *large* source at the 500 lux distance, the resulting L_B is always below 10,000 W/m²sr
 - RG 2 luminance and large source size by necessity >500 lux
 - If it is a *small* source at the 500 lux distance, the resulting E_B is always below 1 W/m²
 - This is a property of white light spectra, hardly influenced by other properties of the light source

Note: The 500 lux measurement does not discriminate if the source would fall into higher RG at shorter distances!

Outcome of the 200 mm measurement


- Nearly all sources are large $\rightarrow L_B$ is determined



Transfer data from light source to fixture

- Optical law: luminance/radiance cannot be **increased** by any optical system
 - remains the same in clear optics
 - is reduced in diffusive optics
- Outcome of L_B measurement can be transferred from light source to lighting fixture!


Information flow (clear optics)




The distance d_{min} is partly determined by the optics of the **fixture**. It is not a value that can be transferred from the source to the fixture without an additional measurement on the light distribution of the fixture.

*Agreement needed on relevant viewing angle.

Relation with CCT and source luminance



Concrete examples of light sources



Conclusions

- The blue-hazard risk correlates mainly with color temperature and source luminance, hardly with spectral details related to lamp technology
- The 200 mm measurement gives more complete information than the 500 lux measurement
 - Can be converted to quantities that give adequate information on maximum exposure time at all distances
 - Gives information that can be transferred from light source to lighting fixture
 - Agreement needed on relevant viewing angle for sources < 2.2 mm

